



Instructions

cutting and attaching the water soluble paper into a tube.

1. Take the water-soluble paper and press it evenly against the end of the pipe so that the outside diameter of the pipe is reflected in its contour.
2. Take a pair of scissors and cut approx. 30 to 50 mm next to the contour (circular for a pipe).
3. Cut from the outside of the cut paper in a star shape up to the contour edge (approx. every 5 - 10 mm, the larger the diameter, the greater the distance).
4. Now insert the cut paper into the end of the tube so that the cut ends of the paper wrap around each other.
5. Now fix the folded ends using the water-soluble adhesive tape and stick it in a circle (tightly).

For external use, use steps 1 – 3 and place the ends over the outside of the pipe and now finish with step 5.

